



Grandstream GXP2140/GXP2160 IP Phone Quick User Guide



Basic Phone Operation

For detailed information please consult the GXP2140/GXP2160 User Manual available at:
www.grandstream.com


©2014 Grandstream Networks, Inc. All rights reserved.

Reproduction or transmittal of the entire or any part, in any form or by any means, electronic or print, for any purpose without the express written permission of Grandstream Networks, Inc. is not permitted. Information in this document is subject to change without notice.


USING THE HEADSET OR SPEAKER

- 1) Use the Speaker Button  to turn speaker ON/OFF.
- 2) Use the Headset button  to use the headset once it had been connected.

MAKING A CALL

- 1) Take Handset/Headset off-hook or press Speaker button or an available LINE key (activates speakerphone) .
- 2) The line will have dial tone and the corresponding line's LED will turn green.
- 3) If you wish, select another LINE key (alternative SIP account).
- 4) Enter the phone number.
- 5) Press the SEND button  or press the "DIAL" soft key.

REDIAL

- 1) Take the phone off-hook.
- 2) Press the SEND button  or press the "REDIAL" soft key.

Note: The phone will redial using the same SIP account as was used for the last call.

ANSWERING CALLS

Single Incoming Call:

- 1) Answer call by taking Handset/Headset off hook or pressing SPEAKER or by pressing the corresponding account LINE button.


Multiple Incoming Calls:

- 1) When there is a call waiting, users will hear a Call Waiting tone .
- 2) The next available line will flash red.
- 3) Answer the incoming call by pressing its corresponding LINE button.
- 4) The current call will be put on hold.
- 5) Toggle between the calls using the LINE button.

ENDING A CALL

End a call by pressing the "EndCall" soft key or hang up the phone.



CALL HOLD/RESUME

- 1) Hold: Place a call on 'hold' by pressing the hold button .
- 2) Resume: Resume call by pressing the corresponding blinking LINE.


CALL TRANSFER

Assuming that you are in a call and wish to transfer the call to another party.

Blind Transfer:

- 1) Press transfer button .
- 2) Dial the number and press the send button  to complete transfer of active call.


Attended Transfer:

- 1) Press an idle line key to make a new call and the active LINE will be placed on hold automatically.
- 2) Once the call is established, press transfer button  followed by the LINE button of the held line to transfer the call.
- 3) After the call is transferred, phone will display idle screen.

3-WAY CONFERENCE

Initiate a Conference Call:


Assuming that you are already in a conversation and wish to bring a third party together in a 3-way conference.

- 1) Press conference button  to bring up conference dialing screen.
- 2) Dial the third party number followed by SEND key.
- 3) When the call is established to the third party, press the "ConfCall" soft key to initiate 3-way conference.

Cancel a Conference Call:

- 1) Press "Cancel" soft key in conference dialing screen to resume the two-way conversation.

Hold The Conference:

- 1) Press hold button  to hold the conference call with all parties are on hold;
- 2) Press "ReConf" soft key to resume conference call; or select the corresponding blinking LINE to speak with an individual party.

End The Conference:

The conference will be terminated for all three parties if the conference initiator hangs up or presses "EndCall" soft key.



VOICEMAIL MESSAGE

A blinking red MWI (Message Waiting Indicator) indicates a message is waiting.

- 1) Press the Message button to retrieve the message. An IVR will prompt the user through the process of message retrieval.
- 2) Press a specific LINE to retrieve messages for a specific line account.

Note: Each account requires a voicemail portal number to be configured in the "voicemail user id" field.

MUTE/DELETE

- 1) Press the MUTE button  to mute/unmute the microphone.
- 2) The Mute icon  indicates whether the microphone is muted.

VOLUME ADJUSTMENTS

Use the volume button  to

adjust the ring volume when the phone is idle.

Press the volume button during an active call to adjust the call volume.